

First chassis number by year 1931-40 © Jaguar Daimler Heritage Trust 2012

SSI and SSII 1931-36		SSI all bodies		SSII all bodies	SSII Please Note: 1931-33 cars not built in chassis number order. Chassis numbers shared with Standard Little Nine models of this period.
		from	1931/10	from	
		1931/10	135005	1931/10	124014
		1932/01	135043	1932/01	124282
last 32 models		1932/07	135502	1932/10	134995
first 33 models		1932/10	135503	1932/10	150186
		1933/01	135595	1933/01	154787
last 33 models		1933/09	136751	1933/07	159515
first 34 models		1933/10	247001	1933/10	300001
		1934/01	247206	1934/01	300012
last 34 models		1934/08	248250	1934/08	300750
first 35 models		1934/09	248251	1934/10	300751
		1935/01	248552	1935/01	300919
last 35 models		1935/09	249500	1935/08	301250
first 36 models*		1935/11	248010	1935/11	300137
		1936		1936	
		1936/07	249500	1936/05	301249

*1935 cars re-titled as '1936 models'

SS Jaguar 1935-37		1 1/2 litre saloon	2 1/2 litre saloon tourer			SS 100 2 1/2 litre	
	from	1936/02	from	1935/10	1936/04	from	1936/04
			1935/10	10001			
	1936/02	20001	1936/01	10114	19001	1936/04	18001
last 36 models	1936/07	20700	1936/07	11449	19060	1936/08	18033
first 37 models	1936/08	20701	1936/08	11450	19061	1936/09	18034
	1937/01	21267	1937/01	12438	19085	1937/01	18051
last 37 models	1937/11	22250	1937/07	13445	19105	1937/08	18126

1 1/2 litre cars from 22195 were titled as "1938 models"

SS Jaguar 1937-40		1 1/2 litre saloon	dhc		2 1/2 litre saloon	dhc		3 1/2 litre saloon	dhc
		from	1937/10	1938/03	from	1937/10	1937/10	from	1937/10
		1937/10	50001		1937/10	40001	46001	1937/10	30001
		1938/01	50003	56001	1938/01	40050	46002	1938/01	30006
last 38 models		1938/07	50600	56042	1938/07	40669	46061	1938/07	30545
first 39 models		1938/07	50601	56043	1938/08	40670	46062	1938/08	30546
		1939/01	52197	56361	1939/01	41121	46198	1939/01	30828
last 39 models		1939/06	53754	56643	1939/06	41450	46273	1939/07	31003
first 40 models		1939/07	70001	*	1939/07	80001	*	1939/07	90001
		1940/01	70577	*	1940/07	80128	*		
last 40 models		1940/07	70688	*	1940/07	80135	*	1939/09	90068

*1940 drophead coupe models were given chassis numbers in the saloon car series

		SS 100 2 1/2 litre	3 1/2 litre
		from	1937/10
		1937/10	49001
		1938/01	49029
last 38 models		1938/07	49050
first 39 models		1938/08	49051
		1939/01	49062
last 39 models		1939/07	49064
first 40 models		1939/07	49065**

**only one 1940 model of each