

First chassis numbers by year Daimler SP 250

© Jaguar Daimler Heritage Trust 2012

Daimler SP 250 sports car

No chassis number prefix

No engine number prefix

Body numbers prefixed 737

Note chassis numbers 100000 to 100005 (1958-64) prototypes

	rhd	lhd
from	1959/11	1959/03
1959	100570	100010
1960/01	100598	100089
1961/01	102629	100489
1962/01	103890	101017
1963/01	104131	101554
1964/01	104344	101573
last	104456	101585
in	1964/09	1964/07

Notes:

Cars not always built in strict chassis number order

Not all chassis numbers issued, but in batches as follows:

rhd 100000 to 100005
 100570 to 100759
 101325 to 101509
 102510 to 102834
 103710 to 104456

lhd 100010 to 100569
 100760 to 101324
 101510 to 101585

© Jaguar Daimler Heritage Trust 2012